


6.857 L16

Physical Unclonable Functions (PUFs)

Srini Devadas

Traditional Authentication

- Each IC needs to be **unique**
 - Embed a unique secret key SK in on-chip non-volatile memory
- Use cryptography to authenticate an IC
 - A verifier sends a randomly chosen number
 - An IC signs the number using its secret key so that the verifier can ensure that the IC possesses the secret key



Physical Unclonable Function



A Physical Unclonable Function (PUF) is a function that is:


- Based on a physical system
- Easy to evaluate (using the physical system)
- Hard to predict

A PUF can additionally be:

- **Manufacturer Resistant** (better than unclonable: even the manufacturer cannot produce two identical systems)

Optical Physical Unclonable Functions

- Generate secrets from **a complex physical system**




Variation *inherent* in (natural) manufacturing process

Hard to remove and predict


Persistent

θ




Image

Optical PUFs




Database

θ_1	Image ₁
θ_2	Image ₂
θ_3	Image ₃




Using a PUF as a Key

- A PUF can be used as a key.
- The lock has a **secret** database of challenge-response pairs.
- To open the lock, the key has to show that it knows the response to a challenge.



Silicon PUFs

- Because of random process variations, **no two Integrated Circuits even with the same layouts are identical**
 - Variation is inherent in fabrication process
 - Hard to remove or predict
 - Relative variation increases as the fabrication process advances
- Delay-Based Silicon PUF concept (2002)
 - Generate secret keys from unique delay characteristics of each processor chip♪



Why PUFs?



- PUF can enable secure, low-cost authentication w/o crypto
 - Use PUF as a function: challenge → response
 - Only an authentic IC can produce a correct response for a challenge
 - Inexpensive: no special fabrication technique
- PUF can generate a unique secret key / ID
 - Highly secure: volatile secrets, no need for trusted programming
 - Can integrate key generation into a secure processor
- **Physical security:** PUF secrets are the delays of wires and gates which are harder to extract via microscopy than bits in non-volatile memory

Main Questions




- How to design a PUF circuit for reliability and security?
 - Analog or asynchronous systems are susceptible to noise
 - Need barriers against software modeling attacks (equivalent to cryptanalysis)
- How to use the PUF for authentication and key generation?


Authentication Using PUFs

Low-Cost Authentication

- Protect against **IC/FPGA substitution** and **counterfeits** without using cryptographic operations



An Arbiter-Based Silicon PUF




- Compare two paths with an **identical delay** in design
 - Random process variation determines which path is faster
 - An arbiter outputs 1-bit digital response
- Multiple bits can be obtained by either duplicate the circuit or use different challenges
 - Each challenge selects a unique pair of delay paths

Metrics

- **Security**: Show that different PUFs (ICs) generate different bits
 - **Inter-chip** variation: how many PUF bits (in %) are different between PUF A and PUF B?
 - Ideally, inter-chip variation should be close to 50%
- **Reliability**: Show that a given PUF (IC) can re-generate the same bits consistently
 - **Intra-chip** variation: how many bits flip when re-generated again from a single PUF
 - Environments (voltage, temperature, etc.) can change
 - Ideally, intra-chip variation should be 0%

Arbiter PUF Experiments: 64 and 512 stages

PUF Response: Average Code Distances
128 (2x64) bit, RFID MUX PUF Rev.Ax1 M3 vs. Rev.Ax8 M3 @ +25°C




Attacking a PUF

- Duplication: Make more PUFs from the **original blueprints** and hope for a match.
- Brute-force attack: Exhaustively characterize the PUF by trying **all challenges**.
- **Model building attack**: Try to build a **model** of the PUF that has a significant probability of outputting the same value.
 - Discover hidden delays of wires/gates in a given PUF
- Direct measurement: Open the PUF and attempt to **directly measure** its characteristics.


Arbiter PUF is not a PUF (clonable!)

- Introduced in 2003 paper, shown in same paper to be susceptible to a machine learning model-building attack



Feed-forward Arbiter


- Also introduced in 2003 paper, conjectured to be hard to learn




- Shown in 2008 (Koushanfar) and 2009 (Ruhrmair) to be susceptible to a model-building attack based on evolutionary algorithm

XOR Arbiter PUF

- Can process and combine outputs of multiple PUFs
- Simplest version: XOR operation




4-way XOR Experiments



8-way XOR experiments

PUF Response: Average Code Distances
128 (2x64) bit, RFID MUX PUF Rev.B vs. (synthesized) Rev.Bx2XOR @ +25°C



XOR Arbiter PUF Security Analysis

- Logistic regression with Rprop heuristic is the best machine learning attack currently known on the XOR arbiter
- XOR arbiter is linearized by increasing the number of dimensions in the machine learning problem
 - Number of independent dimensions is $\sim n^k / k!$
- Machine learning runtime complexity grows as $O(n^k)$ for k -way XOR over n -stage PUFs
 - Size of circuit grows as $O(nk)$

XOR Arbiter PUF Modeling Results

Ruhrmair et al, in submission

- $n = 64$, $k = 6$, and $n = 128$, $k = 5$ can be broken in a few days of CPU time on server farm
- Can go up to $k = 8$ with reasonable noise levels
- Increasing n does not increase noise and increases adversary's computational effort
- Open questions:
 - Can we show a hardness result, i.e., learning requires time exponential in k ?
 - Other ways of adding nonlinearity to circuit?

Potential Uses of PUFs

- Limited use transit token ticket



- Anti-counterfeiting applications



Next Time

Secure Processors